




iBEAM® OnSite PTZ 4K Construction Camera with Cellular Communication INSTALLATION INSTRUCTIONS



1. Attach camera to your pole using the provided straps.

2. Attach power/communication enclosure to your pole using the provided straps.

3. Feed the camera's network cable through the cable gland at the bottom of the power/communication enclosure.

Plug the network cable into the power supply's "camera" port.

Tighten the nut on cable gland.

4. Plug the unit into 110V AC power.

5. View your camera by logging in at www.ibeamsystems.com

**Call the iBEAM Support Team at 1.800.403.0688 to verify installation
and to set your camera views.**