


Installation Guide: iBEAM OnSite PTZ 4K Camera with Cellular Communication

1. Attach your camera to a pole or other mounting surface using the provided straps.
2. Attach the communication box to the pole/mounting surface using the provided straps.
3. Gently pull the cable gland out of its seated location, then feed the network cable into the box and reseal the gland.
4. Plug the network cable into the open port of the PoE power supply.
5. Plug the unit into the appropriate power source as indicated on the PoE power supply.
6. After the camera has been mounted and plugged in for 15-20 minutes, you will receive an email with information regarding how to view your camera.
7. **If you don't see this email from our Support Team please feel free to reach out to them at [800.403.0688](tel:800.403.0688) xt. 2 and they can verify the system is online.**
8. *Enjoy!*

Approximate Angle of View Estimator

Use this template on your site plan to estimate the approximate view from different locations.



70° horizontal viewing angle

Max 134.5' of horizontal view for every 100' of distance from the project

43° vertical viewing angle

Max 82.6' of vertical view for every 100' of distance from the project

360° pan